

## Nordik 48TL Black Glass Panel Installation

For Part#: NK48TL-BG900

**WARNING:** This product can expose you to chemicals including Ethylbenzene which is (are) known to the State of California to cause cancer, birth defects, or other reproductive harm. For more information, visit [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)



- Included Parts: (2) Sides Glass Panels, (1) Rear Glass Panel, (2) side panel clips, (2) top panel clips, (2) Rear Glass Support Brackets

Note: When installing black glass panels ensure the textured side of the glass panel is installed on the backside. The smooth side of the panel should face outward.

Note: The side panel clips are shipped flat. Separate clips and bend the metal fingers at a 90° angle. The metal fingers can be trimmed according to your installation. Ensure there is enough material to hold the panel.

### Installation:

1. Remove the safety screen barrier, glass assembly, log set (if installed).
2. Remove the (2) screws securing the front ember bed media tray. Install the front bottom light kit bulbs if they are not already installed. Figure 1.
3. Next remove the left, center, and right burner assemblies by removing the (3) screws that secure each burner assembly to the bottom burner and the floor of the control board. See Figure 2.



- Each side of the fireplace has (2) screws that you will loosen which secure the corner rear glass support brackets. Install the corner brackets first. See Figure 4. Install the rear glass panel by tilting it into the corner brackets.
- Next install the (2) prebent top rear panel clips using the (2) sheet metal screws located in the baffle. See Figure 5.




Figure 3 – Panel Identification




Figure 4 - Rear Glass - Left or Right Support Bracket

6. Install the left and right side glass panels. Use the finger panel clips. The finger panel clips are shipped flat. Separate clips and bend the metal fingers at a 90° angle. The metal fingers can be trimmed according to your installation. Ensure there is enough material to hold the panel. Make sure the panel clip is angled towards the front of the firebox to catch the front of the side glass panel. You will use a screw that is located in the top of the firebox for clip installation. Figure 6.
7. Ensure all glass panels are flat against the firebox. Reinstall previously removed components




Figure 5 - Rear Panel Clip Installation



Figure 6 - Side Panel Clip Installation